

GOODWE



User Manual

Rechargeable Li-ion Battery System

Lynx Home F Series G2

V1.0-2023-05-20

Trademarks

GOODWE and other GOODWE trademarks are trademarks of GoodWe Technologies Co.,Ltd. All other trademarks or registered trademarks mentioned in this manual are owned by the company.

NOTICE

The information in this user manual is subject to change due to product updates or other reasons. This guide cannot replace the product labels or the safety precautions in the user manual unless otherwise specified. All descriptions in the manual are for guidance only.

Content

- 1 About This Manual 01**
 - 1.1 Applicable Model01
 - 1.2 Target Audience01
 - 1.3 Symbol Definition.....01
 - 1.4 Updates02
- 2 Safety Precaution 01**
 - 2.1 General Safety.....01
 - 2.2 Battery Safety01
 - 2.3 Emergency Measures.....03
 - 2.4 EU Declaration of Conformity.....03
- 3 Product Introduction 04**
 - 3.1 Product Overview04
 - 3.2 Application Scenarios06
 - 3.3 Appearance07
- 4 Check and Storage 08**
 - 4.1 Check Before Receiving.....08
 - 4.2 Deliverables08
 - 4.3 Storage09
- 5 System Installation 10**
 - 5.1 Installation Requirements10
 - 5.2 Installing the Battery System.....12
 - 5.2.1 Moving the Equipment 12
 - 5.2.2 Installing the Battery System 12
- 6 Electrical Connection..... 15**
 - 6.1 Safety Precaution15
 - 6.2 Electrical Connection15
 - 6.3 Connecting the PE cable.....17
 - 6.4 Connecting the Power Cable18
 - 6.5 Connecting the Communication Cable19
- 7 System Operation 21**
 - 7.1 Check Before Power ON21
 - 7.2 Power On.....21
 - 7.3 Setting the Battery Parameters22
 - 7.4 Indicator Status24

8 Maintenance	25
8.1 Power OFF the Battery System	25
8.2 Routine Maintenance	26
8.3 Troubleshooting	26
9 Technical Parameters.....	28

1 About This Manual

This manual describes the product information, installation, electrical connection, commissioning, troubleshooting and maintenance. Read through this manual before installing and operating the product. All the installers and users have to be familiar with the product features, functions, and safety precautions. This manual is subject to update without notice. For more product details and latest documents, visit <https://en.goodwe.com/>.

1.1 Applicable Model

This manual applies to the listed models below:




- LX F9.6-H-20
- LX F12.8-H-20
- LX F16.0-H-20
- LX F19.2-H-20
- LX F22.4-H-20
- LX F25.6-H-20
- LX F28.8-H-20

1.2 Target Audience

This manual applies to trained and knowledgeable technical professionals. The technical personnel has to be familiar with the product, local standards, and electric systems.

1.3 Symbol Definition

Different levels of warning messages in this manual are defined as follows:

 DANGER
Indicates a high-level hazard that, if not avoided, will result in death or serious injury.
 WARNING
Indicates a medium-level hazard that, if not avoided, could result in death or serious injury.
 CAUTION
Indicates a low-level hazard that, if not avoided, could result in minor or moderate injury.
NOTICE
Highlights key information and supplements the texts. Or some skills and methods to solve product-related problems to save time.

1.4 Updates

The latest document contains all the updates made in earlier issues.

V1.0 5/20/2023

- First Issue

2 Safety Precaution

Strictly follow the safety instructions in the user manual during the operation.

NOTICE

The products are designed and tested strictly to comply with related safety rules. Read and follow all the safety instructions and cautions before any operations. Improper operation might cause personal injury or property damage as the products are electrical equipment.

2.1 General Safety

NOTICE

- The information in this user manual is subject to change due to product updates or other reasons. This manual cannot replace the safety instructions or labels on the equipment unless otherwise specified. All descriptions in the manual are for guidance only.
- Before installations, read through the user manual to learn about the product and the precautions.
- All operations should be performed by trained and knowledgeable technicians who are familiar with local standards and safety regulations.
- Use insulating tools and wear personal protective equipment (PPE) when operating the equipment to ensure personal safety. Wear anti-static gloves, clothes, and wrist strips when touching electronic device to protect the equipment from damage.
- Strictly follow the installation, operation, and configuration instructions in this manual. The manufacturer shall not be liable for equipment damage or personal injury if you do not follow the instructions. For more warranty details, please visit: <https://www.goodwe.com/support-service/warranty-related>.

2.2 Battery Safety
















DANGER

- High voltage exists during the battery system running. Power off the battery system before any operations to avoid danger. Strictly follow all safety precautions outlined in this manual and safety labels on the equipment during the operation.
- The inverter used with the battery shall be approved by the battery manufacturer. The approved list of battery and the matched inverter can be obtained through the official website.
- Do not disassemble, modify, or replace any part of the battery or the power control unit without official authorization from the manufacturer. Otherwise, it will cause electrical shock or damage the equipment, which shall not be borne by the manufacturer.
- Do not hit, pull, drag, squeeze or step on the equipment or put the battery into fire. Otherwise, the battery may explode.
- Do not place the battery in a high temperature environment. Make sure that there is no direct sunlight and no heat source near the battery. When the ambient temperature exceeds 60 °C, it will cause fire.
- Do not use the battery or the power control unit if it is defective, broken, or damaged. Damaged battery may leak electrolyte.
- To protect the battery pack and its components from damage during transportation, please ensure that the transportation personnel are professionally trained. All operations during the transportation have to be recorded. The equipment shall be kept in balance to avoid falling down.
- The battery equipment is heavy. Please equip the corresponding personnel according to its weight, so that the equipment does not exceed the weight range of the human body can carry, and cause personnel injury.
- Contact after-sales service immediately if the battery is not able to be started. Otherwise, the battery might be damaged permanently.
- Do not move the battery system when it is working. Contact after-sales service if the battery shall be replaced or added.

CAUTION

- Protect the battery system from damage during transportation and storage.
- The transportation must be carried out by trained professionals. All operations during the process have to be recorded.
- Keep the equipment stable to avoid dumping, which can result in equipment damage and personal injuries.
- Place the cables at least 30mm away from the heating components or heat sources, otherwise the insulation layer of the cables may be aging or broken due to high temperature.
- Tie the same type cables together, and place cables of different types at least 30mm apart. Do not place the cables entangled or crossed.

Label Description

	Potential risks exist. Wear proper personal protective equipment before any operations.		Install the equipment away from open flames or fire sources.
	High voltage hazard. High voltage exists during the equipment's running. Ensure the equipment is power off before any operations.		Keep the equipment away from children.
	Operate the equipment properly to avoid explosion.		Do not lift the equipment after the wiring is completed or when the equipment is working.
	The equipment contains corrosive electrolytes. In case of a leak in the equipment, avoid contact the leaked liquid or gas.		Do not disconnect or plug and unplug the DC connectors during the operation of the equipment.
	The battery contains flammable materials, beware of fire.		Recycle regeneration mark.
	Read through the user manual before any operations.		CE Marking
	Pay attention to wear personal protective equipment during installation, operation and maintaining of the equipment.		Grounding point.
	Do not dispose of the equipment with household garbage at its end of life. Dispose it according to local laws and regulations or send it to the manufacturer.	-	-

2.3 Emergency Measures

Battery Electrolyte Leakage

If the battery module leaks electrolyte, avoid contact with the leaking liquid or gas. The electrolyte is corrosive. It will cause skin irritation or chemical burn to the operator. Anyone contact the leaked substance accidentally has to do as following:

- **Breath in the leaked substance:** Evacuate from the polluted area, and seek immediate medical assistance.
- **Eye contact:** Rinse your eyes for at least 15 minutes with clean water and seek immediate medical assistance.
- **Skin contact:** Thoroughly wash the touch area with soap and clean water, and seek immediate medical assistance.
- **Ingestion:** Induce vomiting, and seek immediate medical assistance.

Fire

- The battery may explode when the ambient temperature exceeds 150°C. Poisonous and hazard gas may be released if the battery is on fire.
- In the event of a fire, please make sure that the carbon dioxide extinguisher or Novac1230 or FM-200 is nearby.
- The fire cannot be put out by water or ABC dry powder extinguisher. Firefighters are required to wear full protective clothing and self-contained breathing apparatus.

2.4 EU Declaration of Conformity

GoodWe Technologies Co., Ltd. hereby declares that the inverter without wireless communication modules sold in the European market meets the requirements of the following directives:

- Electromagnetic compatibility Directive 2014/30/EU (EMC)
- Electrical Apparatus Low Voltage Directive 2014/35/EU (LVD)
- Battery Directive 2006/66/EC and Amending Directive 2013/56/EU
- Waste Electrical and Electronic Equipment 2012/19/EU
- Registration, Evaluation, Authorization and Restriction of Chemicals (EC) No 1907/2006 (REACH)

You can download the EU Declaration of Conformity on the official website: <https://en.goodwe.com/>

3 Product Introduction

3.1 Product Overview

Intended usage

The battery system, which consists of a power control unit (PCU for short) and battery modules, can store and release the electric energy according to the requirements of the solar energy storage system. The input and output ports of the energy storage system are high voltage direct current ports.


Model Description

This manual applies to the listed models below:

- LX F9.6-H-20
- LX F12.8-H-20
- LX F16.0-H-20
- LX F19.2-H-20
- LX F22.4-H-20
- LX F25.6-H-20
- LX F28.8-H-20

Model

LX F9.6-H-20




No.	Referring to	Explanation
1	Series code	Lynx Home F Series
2	Usable energy	<ul style="list-style-type: none"> • 9.6: the usable energy of the battery system is 9.6kWh. • 12.8: the usable energy of the battery system is 12.8kWh. • 16.0: the usable energy of the battery system is 16.0kWh. • 19.2: the usable energy of the battery system is 19.2kWh. • 22.4: the usable energy of the battery system is 22.4kWh. • 25.6: the usable energy of the battery system is 25.6kWh. • 28.8: the usable energy of the battery system is 28.8kWh.
3	Product Features	H: high voltage battery
4	Version code	20: version of the battery system is 2.0.

Usable energy description

NOTICE


- The battery system supports capacity expansion. A maximum of nine battery modules can be used to extend the usable energy of the battery system. Expand the battery system capacity in strict compliance with the expansion requirements. Contact the dealer or manufacturer for more details. Failure to follow the requirements may result in an under-voltage, over-voltage or voltage difference fault in the battery system.
- Actual height varies slightly. Refer to the actual installation height.



3.2 Application Scenarios

NOTICE

- A max of eight battery systems can be parallel connected in one energy storage system. Ensure that the usable energy of each battery system is the same.
- Install the circuit breaker between the inverter and the battery and the circuit breaker between the two battery systems in compliance with local laws and regulations.
Recommended specifications:
 - Nominal voltage $\geq 750V$
 - When a single battery system is applied, the nominal current of the breaker between the inverter and the battery: $\geq 50A$.
 - When two battery systems are applied, the nominal current of the breaker between the inverter and the battery: $\geq 100A$, and the nominal current of the breaker between the battery systems: $\geq 50A$.
 - When more than three battery systems are applied, the nominal current of the breaker between the inverter and the battery: $\geq 125A$, and the nominal current of the breaker between the battery systems: $\geq 50A$.



Approved inverter list

Scan the QR code below or visit the official website to get the Approved Battery Options Statement.




GoodWe Inverter



GE Inverter

3.3 Appearance



No.	Parts	Descriptions
1	Battery base	-
2	Battery module	3 to 9 battery modules can be connected in the battery system.
3	Battery serial connection interface	Connects the battery module to the next module or to the power control unit.
4	Power control unit	Controls battery system.
5	Battery system switch	Switches the battery system on or off.
6	DC cable port (BAT)	Connects the DC cables of the battery system to the inverter. Includes two BAT+ ports and two BAT- ports. The two BAT+ or BAT- port are functionally identical.
7	Grounding point	Connects grounding cables to the grounding points for protection.
8	Communication terminal (COM)	Connects the communication cable between the battery and inverter or two batteries. COM1 and COM2 are functionally identical. COM3 is reserved.
9	Power control unit serial connection interface	Connects the power control unit to a battery module.

No.	Parts	Descriptions
10	SOC indicator	<ul style="list-style-type: none"> • SOC indicator: indicates the SOC status of the battery. • Multi-function button indicator
11	Multi-function button indicator	<ul style="list-style-type: none"> • Black start button: In the PV system, the inverter may not work properly when there is no PV power generation and the utility grid is abnormal. Press the multi-function button for 15s to start the battery system and the inverter. The inverter will then enter off-grid mode and the loads can be powered by the battery. • Long press the multi-function button for 15s to power off the battery system. • Combines the SOC indicator and multi-function button indicator to check the battery system working status, alarm status and fault status.
12	Battery installation limit	Fix the battery to prevent it from tilting.
13	Battery base serial connection interface	Connects the power control unit to a battery module.
14	Adjustable feet	Adjusts the distance between the battery base and the ground.
15	Direction arrow for battery base	Ensure that the arrow in the battery base points towards the wall when installing the battery base.

4 Check and Storage














4.1 Check Before Receiving


Check the following items before receiving the product.

1. Check the outer packing box for damage, such as holes, cracks, deformation, and other signs of equipment damage. Do not unpack the package and contact the supplier as soon as possible if any damage is found.
2. Check the product model. If the product model is not what you requested, do not unpack the product and contact the supplier.
3. Check the deliverables for correct model, complete contents, and intact appearance. Contact the supplier as soon as possible if any damage is found.


4.2 Deliverables

Power control unit

				
PCU x 1	Battery base x 1	Waterproof plug for DC connector (6AWG) x 4	Waterproof plug for DC connector (10AWG) x 4	DC connector • Positive x 2 • Negative x 2
				
Termination resistor x 1	M5*12 screw x 8	Adjustable feet x 4	M6 screw x 2	Grounding terminal x 2
				
Expansion bolt x 8	Locking bracket x 8	Documents x 1		



Battery module



4.3 Storage

If the equipment is not to be installed or used immediately, please ensure that the storage environment meets the following requirements:




1. Do not unpack the outer packing box or throw the desiccant away.
2. Complete the equipment installation in three days after unpacking it. Pack and store the equipment using the original packing box if it is not installed.
3. Stack the equipment complying with the labels and requirements on the packing box.
4. The equipment must be stacked with caution to prevent them from falling.
5. Keep the equipment away from flammable, explosive, and corrosive matters.
6. Place the equipment in a cool place where away from direct sunlight.
7. Store the equipment in a clean place. Make sure the temperature and humidity are appropriate and no condensation.
8. Storage SOC: 25%~50% SOC. Circle the charge-discharge every 6 months.
9. Storage temperature (T):
 - When $-20^{\circ}\text{C} \leq T < 0^{\circ}\text{C}$, the storage period cannot exceed 1 month.
 - When $0^{\circ}\text{C} \leq T \leq 35^{\circ}\text{C}$, the storage period cannot exceed 1 year.
 - When $35^{\circ}\text{C} < T \leq 45^{\circ}\text{C}$, the storage period cannot exceed 1 month.
10. Recommended storage humidity: 0%~95%RH (no condensation). Do not install the battery system if there is any moisture or condensation.


5 System Installation

5.1 Installation Requirements

Installation Environment Requirements

1. Do not install the equipment in a place near flammable, explosive, or corrosive materials.
2. Do not install the equipment in a place that is easy to touch, especially within children's reach. High temperature exists when the equipment is working. Do not touch the surface to avoid burning.
3. Avoid the water pipes and cables buried in the wall when drilling holes.
4. Install the equipment in a sheltered place to avoid direct sunlight, rain, and snow. Build a sunshade if it is needed.
5. Install the equipment in a well-ventilated place to ensure good dissipation. Also, the installation space should be large enough for operations.
6. The equipment with a high ingress protection rating can be installed indoors or outdoors. The temperature and humidity at the installation site should be within the appropriate range.
7. Install the equipment at a height that is convenient for operation and maintenance, electrical connections, and checking indicators and labels.
8. The altitude to install the equipment shall be lower than the maximum working altitude 3000m.
9. Install the product away from electromagnetic interference. If there is any radio or wireless communication equipment below 30MHz near the equipment, make sure that the inverter is at least 30m far away from the wireless equipment.






Mounting Support Requirements

- The mounting support shall be nonflammable and fireproof.
- Install the equipment on a surface that is solid enough to bear the product weight.
- Put the battery system near the wall and install the locking brackets to prevent the battery from falling down.

Installation Angle Requirements

- Install the equipment vertically, no tilt or upside down.



5.2 Installing the Battery System

5.2.1 Moving the Equipment


CAUTION

- Operations such as transportation, turnover, installation and so on must meet the requirements of the laws and regulations of the country or region where it is located.
- Move the equipment to the site before installation. Follow the instructions below to avoid personal injury or equipment damage.
 1. Consider the weight of the equipment before moving it. Assign enough personnel to move the equipment to avoid personal injury.
 2. Wear safety gloves to avoid personal injury.
 3. Keep the equipment in balance to avoid its falling down during moving.

5.2.2 Installing the Battery System

WARNING

- Ensure that the PCU is installed above the battery modules. Do not install any battery modules above the PCU.
- Ensure that the battery system is installed vertically and securely. Align the installation holes of the battery base, battery modules, and PCU. Put the locking bracket cling to the wall, ground, and the battery system.
- Cover the battery system with a cardboard to prevent foreign matters when drilling holes, which may damage the system.
- Remove the cover of the battery module's connection port before installing the battery system.



Step 1: Install thetheadjustable feetto the base.

Step 2: Install the locking bracket to the base.

Step 3: Place the base cling to the wall and mark the drilling positions. Then remove the base.

Step 4: Drill holes using the hammer drill.


Step 5: Check the battery base and ensure that the narrow on the base points to the wall.

Step 6: Screw theexpansion boltsto fix the base.

Step 7: Install the remaining batteries and PCU based on the actual needs.


Step 8: Secure the locking bracket to prevent the PCU from falling down.

Step 9: Check whether the battery system is vertical and secure. Adjust the battery system by the adjust feet if the system is tilted or swayed.



 **WARNING**

- Remove the PCU after marking the drilling positions to avoid damage to the unit when drilling holes using the drill.
- Cover the battery system with a cardboard to prevent foreign matters when drilling holes, which may damage the system.



6 Electrical Connection

6.1 Safety Precaution

DANGER

- High voltage exists during the battery system running. Power off the battery system before any operations to avoid danger. Strictly follow all safety precautions outlined in this manual and safety labels on the equipment during the operation.
- All operations, cables and parts specification during the electrical connection shall be in compliance with local laws and regulations.
- Tie the same type cables together, and place them separately from cables of different types. Do not place the cables entangled or crossed.
- Make sure that the cable conductor is in full contact with the terminal and the cable insulation part is not crimped with the terminal when crimping the terminal. Otherwise, the device may not be able to work properly, or the connection may be unreliable during working, which may cause terminal block damage, etc.

NOTICE


- Wear personal protective equipment like safety shoes, safety gloves, and insulating gloves during electrical connections.
- All electrical connections should be performed by qualified professionals.
- Cable colors in this document are for reference only. The cable specifications shall meet local laws and regulations.

6.2 Electrical Connection

Single Battery System

NOTICE


- The COM1 and COM2 ports are of the same function. Make sure that one communication port is connected to the inverter and the other is fitted with a termination resistor. The battery system cannot work properly if the termination resistor is not installed.
- The COM3 port is reserved. Do not connect any cable to the port.



Parallel Connected Battery Systems

NOTICE


- A max of eight battery systems can be parallel connected in one energy storage system. Ensure that the usable energy of each battery system is the same.
- The COM1 and COM2 ports are of the same function. Make sure that one communication port is connected to the inverter and the other is fitted with a termination resistor. Make sure that a termination resistor is installed to the battery system N. The battery system cannot work properly if the termination resistor is not installed.
- The COM3 port is reserved. Do not connect any cable to the port.



6.3 Connecting the PE cable

NOTICE


- Connect the PE cable first before installing the equipment. Disconnect the PE cable before dismantling the equipment.
- Make sure that the drawing force of the cable after crimping is greater than 400N.
- The PE cable should be prepared by the customer. Recommended specifications:
 - Type: single-core outdoor copper cable
 - Cross-sectional area: 4-6mm²



6.4 Connecting the Power Cable

WARNING


- The DC cable should be prepared by the customer. Recommended specifications:
 - Type: single-core outdoor copper cable
 - Conductor cross-sectional area S : $4\text{mm}^2 \leq S \leq 6\text{mm}^2$ or $14\text{mm}^2 \leq S \leq 16\text{mm}^2$
- When the cross-sectional area range of the conductor is $4\text{mm}^2 \leq S \leq 6\text{mm}^2$, a 10AWG DC connector (included in the deliverables) should be used. The drawing force of the cable after crimping should be greater than 500N. DC cables in this range can only be used to connect a single battery system. Do not cluster battery systems together as this may result in damage to the system.
- When the cross-sectional area range of the conductor is $14\text{mm}^2 \leq S \leq 16\text{mm}^2$, a 6AWG DC connector (included in the deliverables) should be used. The drawing force of the cable after crimping should be greater than 1200N.
- Select the crimping tool based on actual needs. The figure below is for reference only.
- Do not remove the cover of the DC cable port if the DC cable is not to be connected. Otherwise, the protection degree may be influenced.



6.5 Connecting the Communication Cable

WARNING

- If the communication cable between the inverter and the battery system is supplied by the inverter manufacturer, you can decide whether to use the supplied cable or not according to the actual situation. Refer to the user manual of the inverter for detailed cable specifications.
- If you need to prepare the communication cable, the recommended specifications are: standard network cable and RJ45 connector.



PIN Definition

PIN	COM1	COM2	Description
1	RS485A	RS485A	Connects to external devices communicate via RS485, like the LCD screen.
2	RS485B	RS485B	
3	-	-	Reserved
4	CAN_1H	CAN_1H	Connects to the communication port of the inverter.
5	CAN_1L	CAN_1L	
6	PWM-	PWM-	Detects the cluster signal of the battery systems.
7	PWM+	PWM+	
8	-	-	Reserved

 **WARNING**


- Detailed requirements for communication cable connection and termination resistor installation can be obtained in the system wiring network. This chapter only describes the connection method of communication cables and port definitions.
- If the termination resistor is not installed, the Interlock Failure will occur, and the battery system cannot work correctly.

Connecting the Communication Cable

Step 1: Disassemble the waterproof module.

Step 2: Run the communication cable through the waterproof module.

Step 3: Connect the communication cable to the battery system. Tighten the waterproof module.




Installing the Termination Resistor

Step 1: Disassemble the waterproof module.

Step 2: Run the communication cable through the waterproof module.

Step 3: Connect the communication cable to the battery system. Tighten the waterproof module.



7 System Operation

7.1 Check Before Power ON

Check the following items before power on to avoid the battery system being damaged.

No.	Checking Item
1	The system is firmly installed in a clean place where is well-ventilated and easy to operate.
2	The PE cable, power cable, communication cable, and termination resistor are connected correctly and securely.
3	Cable ties are intact, routed properly and evenly.
4	Unused ports and terminals are sealed.

7.2 Power On

NOTICE

- The equipment in the dashed boxes are optional.
- Install the circuit breaker between the inverter and the battery and the circuit breaker between the two battery systems in compliance with local laws and regulations.
- Strictly follow the power on requirements to avoid damaging the system.
- To ensure effective protection, the cover of the battery system switch should remain closed. The cover can be closed automatically after being opened. Fasten the cover with screws if the switch is not to be used for a long-term period.


Method I:

Step 1: Turn on the breaker between the inverter and the battery system.

Step 2: (Optional) Turn on the breaker between the battery systems if they are clustered.

Step 3: Turn on the battery system switch. Turn on the switches of the battery systems in turn if they are clustered.

Step 4: Turn on the inverter in the system following the instructions in the user manual of the inverter.



NOTICE

After powering on the battery system, ensure that the inverter communicates with the battery system properly within 15 minutes. If the inverter cannot communicate properly with the battery system, the battery system switch will automatically disconnect and power off the battery system.


Method II:

Step 1: Long press the multi-function button for at least 15s to start the battery system.


7.3 Setting the Battery Parameters**NOTICE**

Select the battery model via SolarGo app after powering on the battery system. So that the battery system can work properly.

Step 1: Download SolarGo app.




Step 2: Connects inverter to the app.



Step 3: Tap **Home > Parameters > Basic Setting** to set the basic parameters. Follow the prompts to select and set the battery model.

NOTICE









Select the wrong battery model may cause system failure. Ensure that the battery model is right.




Lynx Home F Series G2

7.4 Indicator Status

Normal status

SOC indicator status 	Button Indicator status 	Battery system status
SOC indicator indicates SOC of the battery system.	Green light blink 1 time/s	The battery system is in standby status
 SOC<5%  5%≤SOC<25%  25%≤SOC<50%	Green light blink 2 times/s	The battery system is in idle status.
 50%≤SOC<75%  75%≤SOC<95%  95%≤SOC≤100%	Steady green light	The battery system is in charging status.
The last SOC indicator blinks 1 time/s. <ul style="list-style-type: none"> • When 5%≤SOC<25%, SOC 1 blinks. • When 25%≤SOC<50%, SOC 2 blinks. • When 50%≤SOC<75%, SOC 3 blinks. • When 75%≤SOC<95%, SOC 4 blinks. • When 95%≤SOC≤100%, SOC 5 blinks. 	Steady green light	The battery system is in discharging status.

Abnormal status

Button indicator 	Battery system status	Solutions
Red light blink 2 times/s	Battery system alarm	Once an alarm occurs, the battery system will perform a self-check. After the battery system self-check is complete, the battery system enters operation or fault mode.
Steady red light	Battery system fault	Check both the button indicator and the SOC indicator status to determine the fault that has occurred and handle the problem follow the methods recommended in the Troubleshooting section.

8 Maintenance

8.1 Power OFF the Battery System

⚠ DANGER

- Power off the battery system before operations and maintenance. Otherwise, the equipment may be damaged or electric shocks may occur.
- Strictly follow the power off requirements to avoid damaging the system.

NOTICE

- The equipment in the dashed boxes are optional.
- Install the circuit breaker between the inverter and the battery and the circuit breaker between the two battery systems in compliance with local laws and regulations.
- To ensure effective protection, the cover of the battery system switch should remain closed. The cover can be closed automatically after being opened. Fasten the cover with screws if the switch is not to be used for a long-term period.


Method I:

Step 1: Turn off the inverter in the system following the instructions in the user manual of the inverter.

Step 2: Turn off the circuit breaker between the inverter and the battery.

Step 3:(Optional) Turn off the breakers between the battery systems if they are clustered.

Step 4: Turn off the battery system switch. Turn off the switches of the battery systems in turn if they are clustered.



Method II:

Step 1: Turn off the inverter in the system following the instructions in the user manual of the inverter.

Step 2: Long press the multi-function button indicator for more than 15s, and make sure that the SOC indicator and multi-function button indicator of the PCU are off.

8.2 Routine Maintenance** WARNING**

- Contact the after-sales service for help if you find any problems that may influence the battery or the hybrid inverter. Disassemble without permission is strictly forbidden.
- Contact after-sale service for help if the copper conductor is exposed. Do not touch or disassemble privately because the high voltage danger exists.
- In case of other emergencies, contact the after-sales service as soon as possible. Operate following the instructions or wait for the after-sales service personnel.



















Maintaining Item	Maintaining Period
Check whether the locking bracket is secured, tighten it if not.	Once every 6 months
Check whether the outer enclosure is broken. Repair the painting or contact the after-sales service if there is any broken.	Once every 6 months
Check whether the cables are exposed. Replace the exposed cable or contact the after-sales service for help.	Once every 6 months
Check whether there is any dust around the battery module. Clean the dust if there is any to avoid affecting heat dissipation.	Once every 6 months
Check whether there is any liquid or pest near the battery to avoid intrusion in a long term.	Once every 6 months







8.3 Troubleshooting

The battery system may power off automatically and some functions may not work properly once the battery system fails. Follow the troubleshooting methods below. If the troubleshooting methods cannot solve the problem, contact the after-sales service. Collect the information below before contacting the after-sales service, so that the problems can be solved quickly.

1. Battery information, such as: serial number, software version, when the device was installed, when the fault occurred, how often it occurred, etc.
2. Ambient environment, such as: weather conditions and installation environment. Photos, videos and other files can be provided to assist in the analysis of the problem.



SOC indicator status	Fault	Solutions
	Battery Overvoltage	Power off and wait for 2 hours. Contact the after-sale service if the problem persists.
	Battery Undervoltage	Contact the after-sale service.
	High Cell Temperature	Power off and wait for 2 hours. Contact the after-sale service if the problem persists.
	Low Charging Temperature	Power off and wait for the temperature to recover. Contact the after-sale service if the problem persists.
	Low Discharging Temperature	Power off and wait for the temperature to recover. Contact the after-sale service if the problem persists.
	Overcurrent Charging	Restart the battery. Contact the after-sale service if the problem persists.
	Overcurrent Discharging	Restart the battery. Contact the after-sale service if the problem persists.
	Low Insulation Resistance	Contact the after-sale service.
	Temperature Difference Exception	Power off and wait for 2 hours. Contact the after-sale service if the problem persists.
	Voltage Difference Exception	Restart the battery and leave it for 12 hours. Contact the after-sale service if the problem persists.
	Inconsistent Cell	Contact the after-sale service.
	Wire Harness Exception	Restart the battery. Contact the after-sale service if the problem persists.
	Relay Connection Failure	Restart the battery. Contact the after-sale service if the problem persists.
	Relay Adhesion	Restart the battery. Contact the after-sale service if the problem persists.
	Cluster Fault	Check the battery model. Contact the after-sale service if the battery model is incorrect.
	Interlock Failure	Check whether the termination resistor is installed properly and restart the battery. Contact the after-sale service if the problem persists.
	BMU Communication Fault	Restart the battery. Contact the after-sale service if the problem persists.
	MCU Internal Communication Fault	Restart the battery. Contact the after-sale service if the problem persists.

	Air Switch Adhesion	Contact the after-sale service.
	Precharge Failure	Restart the battery. Contact the after-sale service if the problem persists.
	Relay Overtemperature	Power off and wait for 2 hours. Contact the after-sale service if the problem persists.
	Current Diverter Overtemperature	Power off and wait for 2 hours. Contact the after-sale service if the problem persists.
	Reverse Connection Fault	Contact the after-sale service.
	Microelectronic Fault	Contact the after-sale service.

9 Technical Parameters

Technical Parameters		LX F9.6-H-20	LX F12.8-H-20	LX F16.0-H-20	LX F19.2-H-20
Usable Energy (kWh) ¹		9.6	12.8	16.0	19.2
Battery Module		LX F3.2-20: 64V 3.2kWh			
Number of Modules		3	4	5	6
Cell Type		LFP (LiFePO ₄)			
Nominal Voltage (V)		192	256	320	384
Operating Voltage Range (V)		172.2 ~ 216.6	229.6 ~ 288.8	287 ~ 361	344.4 ~ 433.2
Nominal Dis-/Charge Current (A) ²		35			
Nominal Power (kW)		6.72	8.96	11.2	13.44
Operating Temperature Range (°C)		Charge: 0~+50; Discharge: -20 ~ +50			
Relative Humidity		0~95%			
Max. Operating Altitude (m)		3000			
Communication		CAN			
Weight (kg)		120	154	188	222
Dimensions (W×H×D mm)		600×715×380	600×871×380	600×1027×380	600×1183×380
Ingress Protection Rating		IP55			
Mounting Method		Grounded			
Standard and Certification	Safety	IEC62619, IEC62040-1, IEC63056, VDE2510, CE , CEC			
	EMC	CE, RCM			
	Transportation	UN38.3			
<p>*1: Test conditions, 100% DOD, 0.2°C charge & discharge at +25±2 °C for battery system at beginning life. System Usable Energy may vary with different Inverter.</p> <p>*2: Nominal Dis-/Charge Current and power derating will occur related to Temperature and SOC.</p> <ul style="list-style-type: none"> • When a single battery system is applied, the Nominal Dis-/Charge Current is 35A. • When two battery systems are applied, the Nominal Dis-/Charge Current is 70A. • When more than three battery systems are applied, the Nominal Dis-/Charge Current is 100A. 					


Technical Parameters		LX F22.4-H-20	LX F25.6-H-20	LX F28.8-H-20
Usable Energy (kWh) ¹		22.4	25.6	28.8
Battery Module		LX F3.2-20: 64V 3.2kWh		
Number of Modules		7	8	9
Cell Type		LFP (LiFePO ₄)		
Nominal Voltage (V)		448	512	576
Operating Voltage Range (V)		401.8 ~ 505.4	459.2 ~ 577.6	516.6 ~ 649.8
Nominal Dis-/Charge Current (A) ²		35		
Nominal Power (kW)		15.68	17.92	20.16
Operating Temperature Range (°C)		Charge: 0~+50; Discharge: -20 ~ +50		
Relative Humidity		0~95%		
Max. Operating Altitude (m)		3000		
Communication		CAN		
Weight (kg)		256	290	324
Dimensions (W×H×D mm)		600×1339×380	600×1495×380	600×1651×380
Ingress Protection Rating		IP55		
Mounting Method		Grounded		
Standard and Certification	Safety	IEC62619, IEC62040-1, IEC63056, VDE2510, CE , CEC		
	EMC	CE, RCM		
	Transportation	UN38.3		
<p>*1: Test conditions, 100% DOD, 0.2°C charge & discharge at +25±2 °C for battery system at beginning life. System Usable Energy may vary with different Inverter.</p> <p>*2: Nominal Dis-/Charge Current and power derating will occur related to Temperature and SOC.</p> <ul style="list-style-type: none"> • When a single battery system is applied, the Nominal Dis-/Charge Current is 35A. • When two battery systems are applied, the Nominal Dis-/Charge Current is 70A. • When more than three battery systems are applied, the Nominal Dis-/Charge Current is 100A. 				



Official Website

GoodWe Technologies Co.,Ltd.

 No. 90 Zijin Rd., New District, Suzhou, 215011, China

 T: 400--998--1212

 www.goodwe.com

 service@goodwe.com



Contact Information